

When a fire breaks out in a building the safety of individuals is paramount, and in this respect frame performance is of secondary importance. Unless quickly brought under control, a fire can intensify and spread at frightening speed and therefore it is important to have warning devices installed to allow people to get out of the building as quickly as possible. Smoke and heated air and or asphyxiating gases are responsible for about 75% of fatalities in house fires.